Waterproofing: checks before handover

Use a complete compatible system and record concealed work.

Build Supply | SulfRock | Intelligent Panel Systems | HomePod

1 Substrate and falls

Check soundness, dryness limits, drainage falls and outlet levels against the chosen system design.

2 Product and preparation

Confirm compatible primer, membrane, reinforcement and protection. Follow mixing and application instructions.

3 Joints and penetrations

Use approved details for corners, movement joints, upstands, outlets and pipe entries.

4 Weather and thickness

Record application conditions, coverage and specified thickness. Allow the required cure before subsequent work.

5 Protect the membrane

Use the specified protection for traffic and later trades. Screed is appropriate only where the system requires it.

6 Choose the test

Agree the inspection and integrity-test method. Flood testing requires suitable construction, load checks and manufacturer approval.

Record the detail, inspect it and test by a method suitable for that system.

REFERENCE GUIDANCE

LRWA: liquid waterproofing design guidance
LRWA: technical guidance and testing

Use current product instructions and the approved project design. For regulations, confirm the UK nation, applicable edition and transitional arrangements.

Help us keep our information accurate.

If you notice an error, outdated information or something that needs clarification in this document, please let us know.
Report an Issue: Visit our website and select Report a Website or Document Issue.
buildsupplyltd.co.uk